


Parts Diagram

Danfoss Diverting Valve & Install

Typical for 122°F (50°C)/131°F (55°C)
/ 140°F (60°C) Thermostats

If pump is located in the house or building, install diverting valve after the pump. Always use proper sized circulating pump.



The ESBE VTC thermic valve is a thermostatic by-pass valve which regulates the temperature of either the supply out or the return of water in a hydronic heating system.

In a conventional application, the VTC valve safeguards noncondensing boilers against corrosion from condensation that would result if a minimum flue gas temperature is not maintained. With the VTC the boiler is able to recover and keep up with the drop in water temperature.

The VTC valve can also be used on a solid fuel boiler or a solar application where a minimum or maximum water temperature is trying to be maintained.

